


 PILOTO TIPO SIT 1 CHAMA SKU: 6000559 Pilot Tipo SIT 1 chama Marcas BERTOS, ELECTROLUX, GIGA, MASTRO, WHIRLPOOL	 PILOTO TIPO SIT 2 CHAMAS (VERTICAL) SKU: 6000560 Pilot Tipo SIT 2 Chamas (Vertical) Marcas UNIVERSAL
 PILOTO TIPO SIT 3 CHAMAS (VERTICAL) SKU: 6000565 Pilot Tipo SIT 3 Chamas (Vertical) Marcas UNIVERSAL	 PILOTO TIPO SIT 2 CHAMAS (HORIZONTAL) SKU: 6000569 Pilot Tipo SIT 2 chamas (Horizontal) Marcas ELECTROLUX, MASTRO, MODULAR
 PILOTO 3 CHAMAS (HORIZONTAL) SKU: 6000570 Pilot 3 chamas (Horizontal) Marcas UNIVERSAL	 PILOTO 3 CHAMAS (HORIZONTAL) SKU: 6000571 Pilot 3 chamas (Horizontal) Marcas UNIVERSAL
 PILOTO TIPO SIT 1 CHAMA (VERTICAL) SKU: 6000572 Pilot Tipo SIT 1 Chama (Vertical) Marcas UNIVERSAL	 PILOTO TIPO SIT 1 CHAMA (HORIZONTAL) SKU: 6000585 Pilot Tipo SIT 1 Chama (Horizontal) Marcas UNIVERSAL
 PILOTO TIPO SIT 2 CHAMAS (HORIZONTAL) SKU: 6000586 Pilot Tipo SIT 2 Chamas (Horizontal) Marcas UNIVERSAL	 PILOTO TIPO SIT 3 CHAMAS (HORIZONTAL) SKU: 6000587 Pilot Tipo SIT 3 Chamas (Horizontal) Marcas UNIVERSAL
 PILOTO TIPO SIT 2 CHAMAS (HORIZONTAL) SKU: 6000591 Pilot Tipo SIT 2 Chamas (Horizontal) Marcas UNIVERSAL	 PILOTO TIPO SIT 1 CHAMA (HORIZONTAL) SKU: 6000592 Pilot Tipo SIT 1 Chama (Horizontal) Marcas GIGA, MASTRO, START

**PILOTO TIPO SIT C/ FIXAÇÃO DE TOPO****SKU:** 6000593

Piloto Tipo SIT C/ fixação de Topo

Marcas

GICO, MARENO