

 PRATO DE MICRO-ONDAS Ø 243 MM SKU: 4571431 Prato de Micro-ondas Ø 243 mm Marcas MOULINEX, UNIVERSAL	 PRATO DE MICRO-ONDAS Ø 280 MM SKU: 4571432 Prato de Micro-ondas Ø 280 mm Marcas MOULINEX, UNIVERSAL
 PRATO DE MICRO-ONDAS Ø 328 MM SKU: 4571433 Prato de Micro-ondas Ø 328 mm Marcas MOULINEX, UNIVERSAL	 PRATO DE MICRO-ONDAS Ø 245 MM SKU: 4571435 Prato de Micro-ondas Ø 245 mm Marcas ORIMA, UNIVERSAL, VESTEL
 PRATO DE MICRO-ONDAS Ø 270 MM SKU: 4571436 Prato de Micro-ondas Ø 270 mm Marcas ORIMA, UNIVERSAL, VESTEL	 PRATO DE MICRO-ONDAS Ø 270 MM SKU: 4571439 Prato de Micro-ondas Ø 270 mm Marcas BALAY, BOSCH, DAEWOO, LYNX, SIEMENS, TEKA, UFESA
 PRATO DE MICRO-ONDAS Ø 288 MM SKU: 4571440 Prato de Micro-ondas Ø 288 mm Marcas SAMSUNG, UNIVERSAL	 PRATO DE MICRO-ONDAS Ø 318 MM SKU: 4571441 Prato de Micro-ondas Ø 318 mm Marcas SAMSUNG, UNIVERSAL
 PRATO DE MICRO-ONDAS Ø 345 MM SKU: 4571442 Prato de Micro-ondas Ø 345 mm Marcas SAMSUNG, UNIVERSAL	 PRATO DE MICRO-ONDAS Ø 244 MM SKU: 4571446 Prato de Micro-ondas Ø 244 mm Marcas LG, UNIVERSAL
 PRATO DE MICRO-ONDAS Ø 254 MM SKU: 4571447 Prato de Micro-ondas Ø 254 mm Marcas DAEWOO, UNIVERSAL	 PRATO DE MICRO-ONDAS Ø 283 MM SKU: 4571448 Prato de Micro-ondas Ø 283 mm Marcas DAEWOO, UNIVERSAL

 PRATO DE MICRO-ONDAS Ø 324 MM SKU: 4571449 Prato de Micro-ondas Ø 324 mm Marcas DAEWOO, UNIVERSAL	 PRATO DE MICRO-ONDAS Ø 345 MM SKU: 4571450 Prato de Micro-ondas Ø 345 mm Marcas SAMSUNG, UNIVERSAL
 PRATO DE MICRO-ONDAS C/ ENCAIXE CENTRAL LARGO Ø 288 MM SKU: 4571452 Prato de Micro-ondas C/ Encaixe central Largo Ø 288 mm Marcas SAMSUNG, UNIVERSAL	 PRATO DE MICRO-ONDAS Ø 250 MM SKU: 4571455 Prato de Micro-ondas Ø 250 mm Marcas UNIVERSAL, WHIRLPOOL
 PRATO DE MICRO-ONDAS Ø 262 MM SKU: 4571462 Prato de Micro-ondas Ø 262 mm Marcas UNIVERSAL, WHIRLPOOL	 PRATO DE MICRO-ONDAS Ø 280 MM SKU: 4571467 Prato de Micro-ondas Ø 280 mm Marcas UNIVERSAL, WHIRLPOOL
 PRATO DE MICRO-ONDAS Ø 272 MM SKU: 4571472 Prato de Micro-ondas Ø 272 mm Marcas SHARP, UNIVERSAL, WHIRLPOOL	 PRATO DE MICRO-ONDAS Ø 318 MM SKU: 4571477 Prato de Micro-ondas Ø 318 mm Marcas UNIVERSAL, WHIRLPOOL
 PRATO DE MICRO-ONDAS Ø 245 MM C/ CRUZETA E EXCÊNTRICO SKU: 4571497 Prato de Micro-ondas Ø 245 mm C/ cruzeta e Excêntrico Marcas UNIVERSAL	